



Practical 08: Creating and configuring database instance

Step 01: In the AWS Management Console, on the Services menu, choose VPC

Snapshot:



Step 02: In the left navigation pane, choose Security Groups.






Step 03 : Choose Create security group and then configure:

O Security group name: DB Security Group

o **Description**: Permit access from Web Security Group


o **VPC**: Lab VPC

Snapshot:




Step 04: In the Inbound rules pane, choose Add rule.


- O Type: MySQL/Aurora (3306)
- o CIDR, IP, Security Group or Prefix List: Type sg and then select Web Security Group.
- Choose Create security group








Step 05: On the Services menu, choose RDS.





Step 06: In the left navigation pane, choose Subnet groups.

Snapshot:




Step 07 : Choose Create DB Subnet Group then configure:

o Name: DB-Subnet-Group


o **Description**: DB Subnet Group


O VPC: Lab VPC





Step 08 : Scroll down to the Add Subnets section. Expand the list of values under Availability Zones and select the first two zones: us-east-1a and us-east-1b. Expand the list of values under Subnets and select the subnets associated with the CIDR ranges 10.0.1.0/24 and 10.0.3.0/24 Than Choose Create.









Step 09 : In the left navigation pane, choose Databases. Choose Create database.

Snapshot:




Step 10: Select MySQL under Engine Options.





Step 11: Under Templates choose Dev/Test Under Availability and durability choose Multi-AZ DB instance.

Snapshot:




Step 12: Under Settings, configure:

DB instance identifier: lab-db

Master username: main

Master password: lab-password Confirm password: lab-password






Step 13: Under DB instance class, configure:


- O Select Burstable classes (includes t classes).
- o Select db.t3.micro
- Under Storage, configure:
 - Storage type: General Purpose (SSD)
 - Allocated storage: 20

Snapshot:



Step 14: Under Connectivity, configure:

O Virtual Private Cloud (VPC): Lab VPC.






Step 15: Under Existing VPC security groups, from the dropdown list:


- Choose DB Security Group.
- Deselect default.

Snapshot:




Step 16: Expand Additional configuration, then configure:


- Initial database name: lab
- Uncheck Enable automatic backups.
- Uncheck Enable encryption
- Uncheck Enable Enhanced monitoring. Than Choose Create database








Step 17: Choose lab-db (choose the link itself).






Step 18: Wait until Info changes to Modifying or Available.

Snapshot:




Step 19: Scroll down to the Connectivity & security section and copy the Endpoint field.





Step 20 : To copy the WebServer IP address, choose on the Details drop down menu above these instructions, and then choose Show. and Open a new web browser tab, paste the WebServer IP address and press Enter.

Snapshot:



3.89.57.153/rds.php




Step 21 : Choose the RDS link at the top of the page then Configure the following settings:

Endpoint: Paste the Endpoint you copied to a text editor earlier

Database: labUsername: main

o Password: lab-password

Choose Submit





Step 22: Test the web application by adding, editing and removing contacts.

